




YH2200

Pos.	Codice	Descrizione	Q.tà
1	0404010304006	HEXAGON SOCKET HEAD CAP SCREW ST4.8x13	4
2	040154505	FRONT HANDLE	1
3	04100614010	DAMPER SPRING	1
4	0404010304007	HEXAGON SOCKET HEAD CAP SCREW ST4.2x16	
5	040101239	BOTTOM HALF STARTER COVER	1
6	040101238	TOP HALF STARTER COVER	1
7	040132012	NYLON SHEATH	1
8	040140018	NYLON ROPE	1
9	040102099	STARTER KNOB	1
10	040141006	STARTER SPRING PLATE	1
11	04100603008	STARTER SPRING	1
12	040109220	STARTER REEL (BIG)	1
13	04100628002	RECOIL SPRING (SMALL)	1
14	040109013	STARTER REEL (SMALL)	1
15	04040204003	WASHER	1
16	04040106002	SCREW ST4.8x16	1
17	040158015	FAN COVER	1
18	04040401032	NUT*M8 (THICKEN)	1
19	040502037	FLY WHEEL	1
20	040211001	VENT	1
21	0404010402210	HEXAGON SOCKET HEAD CAP SCREW M4x20	3
22	04040202002	SPRING WASHER	5
23	04040204002	PLAIN WASHER $\varphi 4 \times \varphi 9 \times 0.8$	3
24	04100614009	DAMPER SPRING	2
25	040143100	ENGINE SUPPORT	1
26	0404010304009	HEXAGON SOCKET HEAD CAP SCREW ST4.2x12	5
27	04100628003	DAMPER SPRING	1
28	040605006	NOZZLE PLATE	1
29	0404010304008	HEXAGON SOCKET HEAD CAP SCREW ST4.2x10	5
30	040143101	ENGINE SUPPORT COVER	1
31	040208005	OIL SEAL	2
32	04035305002	BALL BEARING	2
33	04070104096	LEFT CRANKCASE	1
34	04060306026	CRANKCASE GASKET	1
35	040312081	CRANKSHAFT COMP	1
36	040405001	KEY 3*10	1
37		PIN $\varphi 4 \times 10$	2
38	04070103165	RIGHT CRANKCASE	1
39	0404010402218	HEXAGON SOCKET HEAD CAP SCREW M4x16	9
40	040203006	OIL PUMP NOZZLE	1
41	040315015	OIL PUMP	1
42	0404010402212	HEXAGON SOCKET HEAD CAP SCREW M4x12	4
43	040115008	OIL PUMP COVER	1
44	040614026	WORM WASHER $\varphi 10.1 \times \varphi 17 \times 1.5$	1
45	040116011	WORM	1
46	04035404006	CLUTCH NEEDLE	1

YH2200

Pos.	Codice	Descrizione	Q.tà
47	040304040	CLUTCH DRUM 3/8" EP	1
47	040304040C	CLUTCH DRUM 1/4" EP	1
48	04040204047	CLUTCH WASHER	1
49	040301057	CLUTCH	1
50	04040106002	COUNTERSUNK FLAT TAPPING SCREW ST4.2*12	1
51	0404010304009	HEXACONAL TAPPING SREW ST4.2*12	7
52	040117030	BRAKE SPRING COVER	1
53	040403040	PIN	2
54	04100606023	BRAKE BAND	1
55	040117031	BRAKE BAND BUFFER BLOCK	1
56	04100615004	BRAKE SPRING	1
57	040607005	BRAKE LEVER (SUB)	1
58	040117032	BRAKE LEVER CONNECTING BLOCK	1
59	040403048	PIN $\varphi 3 \times 12$	1
60	040606012	TENSIONER COVER	1
61	040409046	CHAIN ADJUSTING SCREW	1
62	040409047	CHAIN ADJUSTING NUT	1
63	040168002	ADJUSTIN GEAR COVER	1
64	040335016	CHAIN ADJUSTING DRIVING GEAR	1
65	040335017	CHAIN ADJUSTING DRIVEN GEAR	1
66	040330003	BRAKE LEVER (MAIN)	1
67	040608004	BRAKE LEVER FIX SLEEVE	1
68	040107118	TOP HALF BREKE COVER	1
69	04040401035	NUT*M8	2
70	040107119	BOTTOM HALF STARTER COVE	1
71	04060305026	CYLINDER GASKET	1
72	040308075	PISTON	1
73	04040207101	CIRCLIP	2
74	040319008	ANTI-WEAR GASKET	2
75	040310042	PISTON PIN	1
76	04035404008	PISTON NEEDLE	1
77	040309056	PISTON RING	2
78	04040204025	PLAIN WASHER $\varphi 4 \times \varphi 10 \times 0.5$	2
79	/	GROUND LINE	1
80	/	OFF LINE	1
81	040501249	IGNITION COIL	1
82	040503012	SPARK PLUG	1
83	040313145	CYLINDER	1
84	04060307020	MUFFLER GASKET	1
85	04060901099	MUFFLER	1
86	04040202004	SPRING WASHER	3
87	04040204005	PLAIN WASHER $\varphi 5 \times \varphi 9 \times 0.5$	3
88	0404010402351	HEXAGON SOCKET HEAD CAP SCREW M5*25	3
89	0406303020	INTAKE PIPE GASKET	1
90	040202036	INLET PIPE	1
91	040608003	INLET PIPE RING	1

YH2200

Pos.	Codice	Descrizione	Q.tà
92	040307128	CARBURETTOR	1
93	040616063	AIR FILTER SUPPORT	1
94	0404010305001	HEXAGON SOCKET HEAD CAP SCREW M5*40	2
95	040124.27	AIR FILTER	1
96	040125001	BALANCER	1
97	040204108	FUEL PIPE PLATE	1
98	040167005	ELBOW CONNECTOR	1
99	040202037	CARBURETOR INLET PIPE	1
100	040167004	OIL PIPE CONNECTION	2
101	040203107	OIL VACUOLE OUTLET PIPE	1
102	040202038	CARBURETOR INLET PIPE (EXTENDED)	1
103	040321012	FUEL FILTER	1
104	04100612013	CLIP Ø4.5	1
105	040203108	FUEL FILTER INLET PIPE	1
106	04100617004	TUBING PROTECTION SPRING	1
107	04100612011	STEEL WIRE ELASSTIC HOOP	1
108	040153002	PRIMER	1
109	040108073	FRONT HANDLE	1
110	04100611003	TRIGGER SPRING	1
111	040127078	TRIGGER	1
112	04100610014	THROTTLE ROD	1
113	040126076	TRIGGER CONTROL ARM	1
114	040108074	FRONT HANDLE COVER	1
115	040504001	SWITCH (ON/OFF)	1
116	040220009	HANDLE SCREW PLUG COVER	1
117	040623002	AIR FILTER COVER LOCK	1
118	040164043	SPARK PLUG COVER	1
119	040623004	POTHOOK for SPARK PLUG COVER	1
120	040206034	AIR INTAKE RUBBER SLEEVE	1
121	040103242	AIR FILTER COVER	1
122	040623005	POT HOOK for ENGINE	1
123	040630002	FRONT DAMPER FLANGE	1
124	040108075	FRONT DAMPER	1
125	04100609007	FRONT DAMPER SPRING	1
126	04040119001	STEPPED TAPPING SCREW	1
127	040604005	WOODEN TEETH	1
128	040118005	CHAIN CATCHER	1
129	04040110014	TAPPING SCREW ST5.5*13	1
130	040111064	TANK CAP	2
131	040207212	TANK CAP SEALRING	2
132	040113005	OIL PAT	2
133	040207212	OIL PUMP INLET PIPE	1
134	040320008	OIL FILTER	1
135	040802012	BAR COVER	1
136	04080103004	3/8LP 10"GUIDE BAR	1
136	04080103004C	1/4 10"GUIDE BAR	1

YH2200

Pos.	Codice	Descrizione	Q.tà
137	04080303007	3/8LP 10"CHAIN	1
137	04080303007C	1/4 10"CHAIN	1
138	03010521023	BAR & SPROCKET COVER ASS'Y	1
139	03010215021	RECOIL STARTER ASS'Y	1