

PARTS LIST


160-K

CONTENTS


MAIN BODY	-----	2~ 3
GEAR CASE	-----	4~ 5
ENGINE	-----	6~ 9
ACCESSORIES	-----	10~11

1987. 12.


1. 本体



2.ギヤケース




見出番号 Ref. No.	部品番号 Parts No.	部品名称 Parts Name	個数 Q'ty	備考 Remarks
2-1	211468	ギヤケース 2ミ97 Gear case, ass'y	1	2~24774 Incl. 2~24
2	210552	ギヤケース Gear case	1	
3	082092	6カフボルト Bolt	1	M6x8
4	092084	ナベコネジ Screw	3	M5x8
5	210553	マキツキボウシバシ Stabilizer	1	
6	092561	6カフボルト (+Pワ'セット) Bolt	1	M5x25
7	210554	ベアリング Bearing	1	#608
8	210555	ギヤ Gear	1	
9	210556	ハモノジツ Blade axis	1	
10	019585	ベアリング Bearing	1	#6001
11	055185	Cカクドリング Snap ring	1	#28, P+34
12	059394	オイルシール Oil seal	1	D19 28 6
13	054736	ハモノジツカラー Collar, blade axis	1	
14	211470	ピニオンギヤ Pinion gear	1	
15	210560	ベアリング Bearing	1	#609
16	140268	ベアリング Bearing	1	#609Z
17	140269	Cカクドリングシント Snap ring	1	#9, シツ34
18	140270	Cカクドリング Snap ring	1	#24, P+34
19	211177	7アイ11" 21V11" ッキン Packing	1	Ø5.5 x Ø12 x t0.5
20	210557	ハモノボス A Boss (A)	1	
21	140275	ハモノボス B Boss (B)	1	
22	210558	アンテナバシ Stabilizer	1	
23	210309	ハツキサ" 6" ツ Toothed washer	1	ヒツリキツ B-8, Counterclockwise
24	089432	6カフボルト Bolt	1	ヒツリキツ M8x18, Counterclockwise
25	089771	6カフボルト Bolt	1	M5x8.5-7T, トツ
26	210412	ジヨウメンカ11"- 2ミ97 Safety cover, ass'y	1	27~30774 Incl. 27~30
27	210311	ジヨウメンカ11"- Safety cover	1	
28	210413	オサエカ+7" Bracket	1	
29	092555	6カフボルト (+Pワ'セット) Bolt	2	M6x30
30	210313	カ11"- シメツケカ+7" Safety cover bracket	1	



Ref.No.	Parts No.	Parts Name	Q'ty	Ref.No.	Parts No.	Parts Name	Q'ty
3-1	213481 212058	Engine (KE18) TD018D-CF59	1	3-38	944171	Bracket	1
3-2	944599	Crankshaft, ass'y	1	3-39	943837	Washer	2
3-3	944153	Bearing	1	3-40	943647	Clutch shoe	2
3-4	944148	Piston	1	3-41	943646	Clutch pin	2
3-5	944149	Piston ring	1	3-42	943934	Spring	1
3-6	944150	Piston pin	1	3-43	944145	Gasket	2
3-7	944151	Snap ring	2	3-44	944384	Muffler, comp.	1
3-8	944129	Gasket	1	3-45	944144	Stud	2
3-9	944128	Cylinder	1	3-46	071107	Washer	2
3-10	944130	Screw	2	3-47	943174	Spring washer	2
3-11	943833	Shim (t=0.1)	AR	3-48	943949	Nut	2
3-11	943834	Shim (t=0.2)	AR	3-49	944143	Muffler cover	1
3-11	943835	Shim (t=0.4)	AR	3-50	943461	Screw	4
3-11	943836	Shim (t=0.6)	AR	3-51	996401	Shroud	1
3-12	943842	Bearing (#6000C3)	1	3-52	944185	Clamp	1
3-13	943843	Oil seal	2	3-53	996402	Carburetor, ass'y	1
3-14	943841	Bearing (#6200C3)	1	3-54	944141	Gasket	1
3-15	996397	Crank case	1	3-55	996392	Insulator	1
3-16	944159	Gasket	1	3-56	944165	Gasket	1
3-17	071098	Dowel pin	2	3-57	944141	Gasket	1
3-18	943190	Screw	4	3-58	944140	Screen	1
3-19	944553	Crank case	1	3-59	944598	Spacer	1
3-20	071100	Dowel pin	2	3-60	944176	Tube	1
3-21	996388	Igniter	1	3-61	944602	Clip	2
3-22	944184	Screw	1	3-62	944168	Joint	1
3-23	944697	Flywheel	1	3-63	944167	Strainer pipe	1
3-24	996398	Ignition coil	1	3-64	943586	Clip	1
3-25	996399	Grommet	1	3-65	944166	Filter, ass'y	1
3-26	944183	Boit	2	3-66	944601	Fuel tank, ass'y	1
3-27	944191	Tube	1	3-67	943977	Breather	1
3-28	071090	Key	1	3-68	944398	Tank cap	1
3-29	071120	Washer	1	3-69	944172	Damper	4
3-30	901545	Spring washer	1	3-70	944175	Damper	1
3-31	943863	Nut	1	3-71	944174	Damper	1
3-32	943982	Spark plug (BM6A)	1	3-72	944173	Tank band	1
3-33	943771	Spring	1				
3-34	943278	Plug cap	1				
3-35	996400	Housing	1				
3-36	944162	Bracket	1				
3-37	943462	Screw	4				

4-エンジン (2)



Ref.No.	Parts No.	Parts Name	Q'ty	Ref.No.	Parts No.	Parts Name	Q'ty
4-1	996402	Carburetor, ass'y	1	4-41	901518	Spring washer	2
4-2	944198	Strainer	1	4-42	944138	Bolt	2
4-3	944197	Pump diaphragm	1	4-43	996405	Recoil starter, ass'y	1
4-4	944196	Gasket	1	4-44	996406	Case	1
4-5	996403	Pump cover	1	4-45	944230	Spiral spring	1
4-6	944193	Screw	1	4-46	944229	Recoil reel	1
4-7	944195	Spring	1	4-47	944231	Rope	1
4-8	944194	Adjust screw	1	4-48	944232	Handle	1
4-9	996404	Throttle valve	1	4-49	944502	Plate	1
4-10	944204	Screw	1	4-50	996407	Washer	1
4-11	944200	Spring	1	4-51	996395	Screw	1
4-12	944199	Throttle shaft	1	4-52	944705	Pulley	1
4-13	944202	Snap ring	1	4-53	944224	Recoil pawl	1
4-14	944201	Cable adjust	1	4-54	944706	Return spring	1
4-15	944222	Clip	1	4-55	944226	E-ring	1
4-16	944221	Screw	5	4-56	071120	Washer	1
4-17	944206	Spring	1	4-57	943863	Nut	1
4-18	944205	Adjust screw	1	4-58	944170	Bracket	1
4-19	944208	Spring	1	4-59	943986	Screw	4
4-20	944207	Adjust screw	1				
4-21	944213	Needle valve	1				
4-22	944214	Control lever	1				
4-23	944215	Spring	1				
4-24	944216	Pin	1				
4-25	944217	Screw	1				
4-26	944211	Gasket	1				
4-27	944210	Diaphragm	1				
4-28	944209	Plate	1				
4-29	944212	Screw	1				
4-30	944218	Gasket	1				
4-31	944219	Diaphragm	1				
4-32	944220	Cover	1				
4-33	944379	Air filter, ass'y	1				
4-34	944597	Case, comp.	1				
4-35	944381	Plate	1				
4-36	944133	Element	1				
4-37	944136	Plate	1				
4-38	944382	Cap	1				
4-39	944137	Screw	1				
4-40	071104	Washer	2				

5. 付属品

