



3 • ENGINE  
CRANKCASE, CYLINDER




Ref. No	Part No.	Part Name	Q'ty	Remarks
3- 1	265682	Engine	1	AE420/17
3- 2	262544	Cylinder	1	New gasket required
3- 3	262546	Gasket	1	
3- 4	261246	Cap Screw	4	M5x25
3- 5	262548	Insulator	1	New gasket required
3- 6	262550	Air Duct	1	
3- 7	262790	Gasket	2	
3- 8	261246	Cap Screw	2	M5x25
3- 9	262748	Muffler	1	
3-10	262617	Gasket	1	
3-11	261607	Cap Screw	1	M5x16
3-12	262687	Cap Screw	2	M6x65
3-13	265342	Top Cover Ass'y	1	Incl. 14~17
3-14	265343	Top Cover	1	New label required
3-15	262556	Knob	1	
3-16	262689	Spacer	1	
3-17	262690	Snap Ring	1	#6
3-18	265696	Label	1	
3-19	262558	Crankcase	1	
3-20	262658	Bearing	2	#6202C3
3-21	262660	Oil Seal	1	TC15357
3-22	262565	Oil Seal	1	ISCD15257
3-23	012380	Snap Ring	1	H35
3-24	261999	Cap Screw	4	M5x40
3-25	264328	Piston	1	
3-26	262476	Piston Ring	2	(2)Required
3-27	262749	Piston Pin	1	
3-28	262659	Bearing, Needle	1	KTV111414EG01B2
3-29	262479	Clip, Piston Pin	2	
3-30	262567	Crankshaft/Conn. Rod Ass'y	1	
3-31	262577	Clutch Ass'y	1	Incl. 32, 33
3-32	262655	Clutch Shoe	2	(2)Required
3-33	263615	Spring, Clutch	1	
3-34	262683	Washer	2	φ 8X φ 22Xt1. 2
3-35	262682	Wave Washer	2	
3-36	262684	Clutch Bolt	2	M8
3-37	264388	Fan Cover	1	
3-38	261250	Cap Screw	4	M5x20
3-39	263077	Magneto Ass'y	1	Incl. 40~48
3-40	262619	Rotor/Fan	1	

3 · ENGINE  
CRANKCASE, CYLINDER



Ref. No	Part No.	Part Name	Q'ty	Remarks
3-41	263078	Ignition Coil Ass'y	1	Incl. 42~48
3-42	263079	Coil	1	
3-43	262622	Spark Plug Wire Ass'y	1	Incl. 44~46
3-44	262623	Spark Plug Wire	1	
3-45	261074	Plug Boot	1	
3-46	261075	Connector	1	
3-47	261072	Cap	1	
3-48	262694	Insulator	1	φ 6x φ 6. 8x100L
3-49	261076	Woodruff Key	1	
3-50	262731	Nut, Rotor	1	M10
3-51	261078	Spacer	2	
3-52	261256	Cap Screw	2	M4x25
3-53	262483	Spark Plug	1	NGK BPMR6Y
3-54	262717	Wire, Coil Ground	2	
3-55	261202	Grommet	1	
3-56	265695	Label	1	
3-57	262584	Recoil Starter Ass'y	1	Incl. 58~71
3-58	262624	Recoil Ass'y	1	Incl. 59~66
3-59	262631	Rope Ass'y	1	Incl. 60~62
3-60	262633	Starter Grip	1	
3-61	262632	Starter Rope	1	
3-62	262981	Cap	1	
3-63	262627	Spiral Spring	1	
3-64	262626	Pulley	1	
3-65	262982	Washer	1	
3-66	262629	Screw	1	
3-67	262634	Starter Pawl Ass'y	1	Incl. 68~71
3-68	262636	Pawl	1	
3-69	262637	Return Spring	1	
3-70	262635	Pawl Case	1	
3-71	262638	E-Ring	1	
3-72	261257	Cap Screw	4	M4x16
3-73	264520	Label	1	
3-74	081040	Nut	1	M8

4 • ENGINE  
 CARBURETOR, FUEL TANK



Ref. No	Part No.	Part Name	Q'ty	Remarks
4- 1	263873	Carburetor Ass'y	1	Incl. 2~19
4- 2	261871	O-Ring	1	
4- 3	263247	Main Jet	1	#50
4- 4	262995	Gasket	1	
4- 5	262994	Diaphragm, Fuel Pump	1	
4- 6	263725	Pump Body	1	
4- 7	263727	Gasket	1	
4- 8	261873	Diaphragm, Metering	1	
4- 9	263726	Cover Plate	1	
4-10	263737	Screw	4	
4-11	261876	E-Ring	1	
4-12	263249	Throttle Valve Ass'y	1	
4-13	261652	Plug	1	
4-14	261658	Swivel	1	
4-15	261875	Screw	2	
4-16	263250	Bracket	1	
4-17	261878	Nut	1	
4-18	265409	Adapter	1	
4-19	261657	Packing	1	
4-20	262587	Gasket	1	
4-21	263520	Air Filter Ass'y	1	Incl. 22~28
4-22	263723	Housing	1	
4-23	263715	Sleeve	2	
4-24	263007	Choke Valve	1	
4-25	263000	Washer	1	
4-26	263717	Screen	1	
4-27	263714	Foam Element	2	
4-28	263713	Air Filter Cover	1	
4-29	261814	Cap Screw	2	M5x50
4-30	265684	Fuel Tank Ass'y	1	Incl. 31~41
4-31	263676	Fuel Tank	1	
4-32	265582	Fuel Tank Cap Ass'y	1	Incl. 33
4-33	261105	Gasket	1	
4-34	261696	Breather Ass'y	1	
4-35	263677	Fuel Pipe Ass'y	1	Incl. 36, 37
4-36	261339	Grommet	1	
4-37	262649	Fuel Pipe	1	
4-38	261797	Fuel Filter Ass'y	1	
4-39	261117	Clip	1	
4-40	262697	Pad	1	
4-41	261119	Pad	2	
4-42	261117	Clip	1	